

Technical Manual



10.010.01

REMOVE & INSTALL
COOLING ASSEMBLY

STARK FUTURE



SAFETY WARNINGS

Observe your local health and safety guidelines. Ensure a safe working environment. Wear appropriate protective gear. Deviating from the prescribed order may result in injury or damage to the products.



TOOLS

- TRX 30
- Tools of the linked procedures



CONSUMABLES

Coolant fluid



OPERATION TIME

75 Minutes

REMOVAL



WARNING

Before proceeding with any work on the bike, make sure it is turned off and the charger disconnected.

- 1 Remove subframe. Refer to:



05.022.01

[Remove and install subframe ↗.](#)

- 2 Remove the three bolts that hold the radiator.
- 3 Remove the cooling assembly.

INSTALLATION



WARNING

Before proceeding with any work on the bike, make sure it is turned off and the charger disconnected.

- 1 Place the cooling assembly in the subframe.
- 2 Insert and tighten the three radiator bolts to **5 Nm**.
- 3 Install subframe. Refer to:



05.022.01

[Remove and install subframe ↗.](#)



WARNING

Confirm the water pump runs smoothly and that there are no leaks in the cooling system.

starkfuture.com

ENG 2023-08

Copyright © 2023 Stark Future SL. All rights reserved.
Reproduction, even in part, as well as copying of all kinds,
is permitted only with the express written permission
of the copyright owner.

STARK FUTURE