

Technical Manual



**02.002.01**

**REMOVE AND INSTALL  
FRONT BREAK DISC**

**STARK FUTURE**



## SAFETY WARNINGS

Observe your local health and safety guidelines. Ensure a safe working environment. Wear appropriate protective gear. Deviating from the prescribed order may result in injury or damage to the products.



## TOOLS

- TRX 30
- TRX 45
- ALN 10



## CONSUMABLES

Medium strength brake cleaner



## OPERATION TIME

20 Minutes

# REMOVAL



## WARNING

Before proceeding with any work on the bike, make sure it is turned off and the charger disconnected.

- 1 Remove the front wheel. Refer to:



09.001.01

[Remove and Install front wheel ↗.](#)

- 2 Unscrew the brake disc bolts.



## NOTE

Ensure you place the wheel in a secure and comfortable position to work on.

## 3

# INSTALLATION



## WARNING

Before proceeding with any work on the bike, make sure it is turned off and the charger disconnected.

- 1 Align the disc brake holes with the wheel hub holes.
- 2 Clean the brake disc bolts from any debris and apply medium strength thread locker.
- 3 Tighten the brake disc bolts to **14 Nm**.
- 4 Clean the brake disc from any debris with brake cleaner.
- 5 Install the front wheel on the bike.  
Refer to:



09.001.01

[Remove and Install front wheel ↗.](#)

## WARNING

Check brakes operation before operating the bike.

starkfuture.com

ENG 2023-06

Copyright © 2023 Stark Future SL. All rights reserved.  
Reproduction, even in part, as well as copying of all kinds,  
is permitted only with the express written permission  
of the copyright owner.

**STARK FUTURE**