

Technical Manual



02.005.01

**REMOVE AND INSTALL
FRONT BRAKE CALIPER**

STARK FUTURE



SAFETY WARNINGS

Observe your local health and safety guidelines. Ensure a safe working environment. Wear appropriate protective gear. Deviating from the prescribed order may result in injury or damage to the products.



TOOLS

- TRX 45
- Medium strength thread locker



OPERATION TIME

5 Minutes

REMOVAL



WARNING

Before proceeding with any work on the bike, make sure it is turned off and the charger disconnected.

- 1 Unscrew front brake caliper bolts.
- 2 Remove front brake caliper.

INSTALLATION



WARNING

Before proceeding with any work on the bike, make sure it is turned off and the charger disconnected.

- 1 Clean the front brake caliper bolts and apply medium strength thread locker
- 2 Slide the brake caliper onto the front brake disc.
- 3 Tighten the front brake caliper bolts by hand until it holds in place.
- 4 Tighten the front brake caliper bolts to **25 Nm**.



WARNING

Check brake operation before operating the bike.

starkfuture.com

ENG 2023-06

Copyright © 2023 Stark Future SL. All rights reserved.
Reproduction, even in part, as well as copying of all kinds,
is permitted only with the express written permission
of the copyright owner.

STARK FUTURE